



[www.strath.ac.uk](http://www.strath.ac.uk)



# Laser Absorption and plasma coupling

David Neely

Central Laser Facility, STFC, Oxfordshire, UK

University of Strathclyde, Glasgow, Scotland

Kansai Photon Science Institute and PMRC, JAEA, Kyoto, Japan

EMMI workshop

Plasma Physics with Intense Heavy Ion and Laser Beams

GSI, Darmstadt, 2-4<sup>th</sup> May 2011

Rutherford Appleton Laboratory, Chilton, Didcot, Oxon, OX11 0QX, UK.

Telephone: (44)1235 446150 Fax: (44)1235 445888


e-mail: [david.neely@stfc.ac.uk](mailto:david.neely@stfc.ac.uk)



Science & Technology  
Facilities Council

# Introduction – scale length effects

- Pre-plasma effects
  - ns timescales
  - Implications
- ps timescales
  - Implications
- Conclusion



# Real pulse interaction effects




Optical gating  
~ ns rise times




Reflections or  
pre pulses on  
ps timescales

Finite bandwidth  
or phase errors  
explodes thin targets



Pulse profile on the  
Astra Gemini Ti:S  
laser system



# Plasma mirrors for cleaner interactions




# Specular reflectivity $10^{16}$ - $10^{19}$ $\text{Wcm}^{-2}$





Appl. Phys. Lett., 94, 24, 241102, 2009, Pirozhkov, Diagnostics of laser contrast using target reflectivity

# Effect of laser contrast




# Laser Reflection at $10^{21}$ Wcm<sup>-2</sup>



NJP. 10, 083002, 1-12, 2008, Horlein et al, High contrast plasma mirror, spatial filtering and second harmonic generation at  $10^{19}$  Wcm<sup>-2</sup>

# Laser Reflection Measurements







# Double pulse regime of ps pre-pulse studies


## Outline

- Front surface absorption changes ?
- Rear surface Sheath expansion with multiple pulses – theory
- Experimental setup
- Results –

# Multiple Pulse Sheath Acceleration




- Vlasov and PIC simulations by Robinson *et al.* indicate spectral peaks and increase in conversion efficiency with appropriate double pulse configuration.



# Double pulse experimental setup

- Off-axis parabola focuses the beam to a 30 $\mu$ m focal spot. Pulse duration is 0.7ps.
- Intensity in the focus is  $\sim 10^{19}$  Wcm.
- Laser energy is divided into two collinear pulses at a ratio of 0.1:1 (typically 130J on target) and 0.4:1 (typically 57J on target).






- Temporal separation between two pulses is varied between 0 and 2.5 picoseconds.
- Proton spectra monitored with radiochromic film for total integrated flux and Thomson parabola spectrometers for high resolution spectra at discrete angles.

# Integrated dose dual-pulse





Pulse ratio 0.4:1 @ mid $10^{19}$  Wcm $^{-2}$

RCF Beam images

- reduces low energy  $\sim 1.2$ MeV
- increases high energies



# Single Vs Dual-pulse drive




Intensity on target mid  $10^{19} \text{ Wcm}^{-2}$

• Lower pre-pulse must come earlier


# Numerical Simulations

- 1-D particle in cell (PIC) code used to model experimental parameters.
- Several parameters scaled down for run time and numerical heating considerations
  - Laser pulse duration 300fs,  $I_{\text{laser}} = 10^{20}$  W/cm<sup>2</sup>. Higher intensity but shorter pulse than experiment.
  - Target: thickness 10 microns, bulk composition: heavy ions ( $m_{\text{ion}} = 3m_p$ ,  $Z_{\text{ion}} = +1$ ,  $q/m$  same as C<sup>+4</sup>) and 20nm proton layer on front and rear surfaces).  $n_i = n_p = n_e = 8 \times 10^{28}$  m<sup>-3</sup>.




# Numerical Simulations

$t = t_0 - 250\text{fs}$



• **Protons**




• **Ions**




# Numerical Simulations

$t = t_0 - 150\text{fs}$




• Protons




• Ions

# Numerical Simulations

$t = t_0 - 50\text{fs}$




• Protons




• Ions

# Numerical Simulations

$t = t_0 + 50\text{fs}$




• Protons



• Ions

# Numerical Simulations

$t = t_0 + 150\text{fs}$




• Protons


• Ions

# Numerical Simulations

$t = t_0 + 250\text{fs}$




• Protons




• Ions

# Numerical Simulations

$t = t_0 + 350\text{fs}$





• Protons



• Ions

# Dual pulse Ion energy beam data



Increase in flux and  $E_{\text{max}}$ :

- Clearly an optimum delay for maximum conversion efficiency
- Trend with delay appears more abrupt with 0.4: ratio (higher prepulse and lower main pulse intensity and energy than 0.1:1).
- Conversion efficiency boosted by factor of 3.3 for 0.1:1 ratio



[www.strath.ac.uk](http://www.strath.ac.uk)

# Co-workers



P McKenna, C Brenner, D C Carroll, P Gallegos, R Grey,  
University of Strathclyde

F. Nurnberg, M. Roth, M Guentner, K Harres, University of Darmstadt

V. Bagnoud, B. Zielbauer, GSI, Darmstadt

M Borghesi, B Dromey, S Karr, R Prasad, S Ter-Avetisyan, M Zepf,  
Queens University of Belfast

Y T Li, M H Xu, Beijing National Laboratory, China

J Green, J S Collier, F Cameron, P Foster, R Evans, S Hawkes, K Markey, A  
Robinson, C Spindloe, M Tolley  
Central Laser Facility, STFC

M Streeter, N Dover, S R Nagel, C Palmer, J Schreiber, Z Najmudin  
Imperial College, London

C-G Wahlström, Lund Laser Centre, Sweden

Rutherford Appleton Laboratory, Chilton, Didcot, Oxon, OX11 0QX, UK.

Telephone: (44)1235 446150 Fax: (44)1235 445888

e-mail: [david.neely@stfc.ac.uk](mailto:david.neely@stfc.ac.uk)



Science & Technology  
Facilities Council



# Conclusion

- Dual-pulse drive
  - Simple optical control mechanism
  - Increased front surface absorption
    - may play a small role at ps
    - plays a significant role at ns
  - See C Brenner for multi ps details Wed 9:00
- Pulse temporal control
  - Multiple pulses on ps timescale will be required for spectral control
  - ns pre-pulses can have their uses if controlled
  - Slope of rising edge has influence
  - Ultra high contrast essential for some experiments
- Future directions
  - Multi pulse at higher drive energies
  - Specular reflectivity a simple contrast diagnostic
  - Targetry