Non-Destructive Profile Measurement in Rings with Strong Space Charge

R Williamson, B Pine, C Wilcox

With many contributions from ISIS Diagnostics and Accelerator Physics Groups



Contents

- Introduction to ISIS
- Residual Gas Ionisation Monitor
- Simulations
- Measurement errors
- Comparison measurements to simulation
- Profile correction
- Application to operation and R&D
- · Plans for the future



Introduction





Introduction

Circumference: 163 m

Energy: 70–800 MeV

Repetition Rate: 50 Hz

Intensity: Up to 3×10^{13} ppp

Mean Power: Up to 190 kW

Tune Shift: ~0.5


Injection: 130 turn

charge exchange

RF system: h=2, 1.3-3.1 MHz, 160 kV/turn

h=4, 2.6-6.2 MHz, 80 KV/turn


Extraction: single turn, vertical



Extraction



Residual Gas Ionisation Profile Monitor - Principle of Operation




- Non-destructive measurement of beam profile and width
- Ions/electrons produced proportional to beam intensity
- Guided to detector



Residual Gas Ionisation Profile Monitor - ISIS Design

- Compensating electrodes double as calibration device – single channel
- Up to 60 kV drift field
- \cdot 300 π mm mrad, ~100 mm wide average
- 10⁻⁷ mbar in synchrotron






Residual Gas Ionisation Profile Monitor - Detector Development

- Single channel electron multipliers channeltrons®
- Upgrade from one moveable channeltron® (averaged profile) to 40 fixed channeltrons® (single pulse profile)
- · 6 mm centre to centre separation
- Single, moveable channeltron® used to calibrate multichannel




S Whitehead, S Payne, A Pertica et al.


BIW' 10





3D Electrostatic Model

- Beam modelled as concentric cylinders
 - Centred
 - "Normal" beam distributions
- Compensating field










Measurement Error – 2D *Drift Field*

- · Non-uniform electric field
- · Pushes ions outward from central axis
- Measured profile widened
- Feature of monitor geometry




- ↑ Ideal ion path
- ↑ Actual ion path

Measurement Error - Space Charge

1x10¹³ ppp

- Pushes ions out from centre of beam
- Measured profile widened
- Dependent on beam charge, size, energy, distribution, intensity and drift field voltage



B. Pine EPAC '06


Ion Tracking - Full 3D

- Simple in house code
 - Load electric field
 - Create ions distributed evenly throughout beam volume
 - Track ions with zero initial velocity until enter the detector or exit the monitor
 - Weight tracks with beam distribution




Ion Tracking Results

- Combined errors can double the measured profile width in normal running conditions
- Long tails present on profiles




Measurement Error - Longitudinal Drift Field

- · Non-uniform electric field
- · Longitudinal electric potential saddle point
- More complicated ion trajectories
- Not a pure 1D projection



Initial Position of Detected Ions



EPB Profile Study

Check understanding of profile monitor with other diagnostics

Profile

Grid

Position

- Position monitor (planned)

- Ionisation profile monitor

- 3 x SEM grid profile monitors




SEM Grid

Ionisation Profile Monitor


SEM Grid Vs Ionisation Profile

- Measurement at 2.5x10¹³ ppp
- Nominal 15 kV drift field
- 95% width:



Simulation Vs Measurement


- Model beam in ionisation monitor as measured using SEM grid profile monitor
- Simulate resulting profile
- Compare with measured ionisation profile



- Many profile comparisons in the synchrotron confirm model with space charge and drift field
- EPB comparisons promising

Simulated profile (black)
Measured profile (blue)

Profile Correction



x/mm

Error Summary

In decreasing order of importance


- · 2D non-uniform drift field
 - Verification at low intensities
 - ~30% error on width
 - Simple correction
 - Shaping fields


Space charge


- Verification with altering drift field
- Error dependent on beam parameters, drift field, ~30% error on width
- Simple correction for centrally peaked, centred distributions
- Increase drift field voltage

· 3D non-uniform drift field

- Needs to be experimentally verified
- Small effect
- Remove compensating field?








Injection Painting Measurements


- Closed orbit and Relative Betatron amplitude measured over injection
- Results used in ORBIT simulation of painting

Beam distributions generated by ORBIT compared to MCPM measurements at high and low intensity

 Space charge correction applied to HI data




B. Jones EPAC '08



Low intensity

Drift corr.

High intensity Drift and SC corr.




Half Integer Studies

Half integer resonance with space charge

- Key loss mechanism
- Experimental studies 2D coasting beam $\varepsilon_x = \varepsilon_y$, $\varepsilon_{rms} \approx 20 \ \pi$ mm mr, $2Q_y = 7$ driving term, $Q_y = 3.6$ Ramp intensity (1E13 ppp), push onto resonance
- Study evolution of corrected profiles, not just loss
 Observations agree with ORBIT models
 Clear formation of core and lobes Measured
- Using to understand loss mechanism
 1D and 2D models of core-tohalo dynamics
- Good model of profile monitor key

C. Warsop Space Charge '15



Summary

- Good model of the ISIS residual gas ionisation profile monitor
- Measurement errors
 - 2D non-uniform drift field
 - Space charge
 - 3D non-uniform drift field
- Simulations Vs Measurement
- Correction works well for "normal" centred beams
 - Applied in different scenarios
- Key measurements for understanding machines with high space charge



Plans for the Future

 Effectiveness of profile correction for different beam types

- Intensity
- Off-centre
- Unusual beam distributions
- Experimental check of beam width by different methods in the synchrotron
- Characterisation of the channeltrons® in new diagnostic vacuum vessel
- Development of the correction model and the monitor itself








Additional slides



HEDS Monitor

 Newer IPM installed in HEDS space between the Linac and ring in 2010.

- Beam profile here is narrow (~19mm width) so channeltrons not suitable.
- 32 channel micro channel plate (MCP) used to detect ions instead.
- MCP can be rotated 90° to allow for calibration of each channel.
- Shaping field electrodes added to the design to remove widening effect of the drift field.





Stepper motor

and resolver