

Current status and developments for Barrel EMC



V. Dormenev, Ch. Hahn, T. Kuske, M. Moritz,
R. Schubert, M. Straube, U. Thöring,
B. Wohlfahrt, HG Zaunick
JLU Giessen




PANDA CM, EMC
Mar 8, 2017

Activities


- Assembly of preseries slice → Markus
- Crystal production @ Crytur
- HV distribution electronics
- Design of Backplane electronics
- LED crystal damage recovery system
- (Estimation of Cu neutron activation)

HV distribution electronics



Single channel block schematic


- Device to independently adjust bias voltage of 8 APDs
- All channels fed from the same HV source
- Online measurement of APD voltage and current



4-ch prototype
size: 6 x 5.5 cm²


HV distribution electronics

Lab setup for characterization of HV distributor



HV distribution electronics


- HV adjustment done by potentiometer setting



Regulation voltage range set by voltage divider at gate of HV Mosfet


- Current prototype: ~100 V span from HV input downwards
- 10-bit resolution of potentiometer

~0.1V V resolution




HV distribution electronics

Characterization of HV distributor (DUT), not of the APD itself → use standard reference APDs always at the same channels and under identical conditions




HV distribution electronics


Characterization of HV distributor (DUT), not of the APD itself → use standard reference APDs always at the same channels and under identical conditions





HV distribution electronics



HV distribution electronics




HV distribution electronics



- Usable voltage range reflects radiation induced changes (ADC gain)
- No changes (within measurement precision) for ionizing doses up to ~ 170 Gy
- Slight shift at low neutron fluence ($\sim 10^8$ n/cm 2), stable up to 10^{10} n/cm 2 , max. 0.25 V difference
- Same observation for proton fluence up to 10^{10} p/cm 2 (irrad. At KVI, 180MeV)
- Irradiations at fluences of 10^{11} neutrons and protons done. Characterizations pending due to high activation


HV distribution electronics







- Comparison of on-board measured voltage and true output voltage (Keithley multimeter)
- Const offset from component tolerances removed
→ part of channel calibration (Eeprom)

HV distribution electronics


- Temperature dependence of on-board measured voltage
- Temp measurement from on-board sensor, resolution $\sim 0.01\text{K}$
- Temp coeff: $\sim 0.15\text{ V/K}$



Backplane Electronics





Backplane Electronics



Line Drivers

- Need for low power, high density diff. line drivers
- Compensate for cable loss (Bedeac cable), gain > 2



Data Sheet

FEATURES

High performance at low power

High speed

–3 dB bandwidth of 750 MHz, $G = 1$

0.1 dB flatness to 210 MHz, $V_{OUT, dm} = 2 \text{ V p-p}$, $R_{L, dm} = 200 \Omega$

Slew rate: 2900 V/ μs , 25% to 75%

Fast 0.1% settling time of 9 ns

Low power: 9.5 mA per amplifier

Low harmonic distortion

108 dB SFDR @ 10 MHz

98 dB SFDR @ 20 MHz

Low output voltage noise: 9.2 nV/ $\sqrt{\text{Hz}}$, $G = 1$, RTO

$\pm 0.2 \text{ mV}$ typical input offset voltage

Selectable differential gains of 1, 2, and 3

Differential-to-differential or single-ended-to-differential operation

Adjustable output common-mode voltage

Input common-mode range shifted down by 1 V_{BE}

Wide supply range: +3 V to $\pm 5 \text{ V}$

Available in 16-lead and 24-lead LFCSP packages

Low Power, Selectable Gain
Differential ADC Driver, $G = 1, 2, 3$

ADA4950-1/ADA4950-2

FUNCTIONAL BLOCK DIAGRAMS





Figure 1. ADA4950-1



Backplane Electronics


Drive of blue LED for stimulated recovery of crystals

Bpl-Connector to FE ASIC PCB


Added line for LED drive

Requirements:

- Up to 20 mA drive current
- Ideal RF decoupling to Gnd at several places along the line!




Backplane Electronics



Lower PCB

- Connectors to FEs
- 8x2 Diff. Line drivers
- Vregs: low noise, high PSRR
- APFEL I/F buffers
- Temp/Humidity sensors




Upper PCB

- HV regulators, distribution, measurements
- Eeprom for regulator calibrations
- One HV in, outputs routed to lower board via 100pin HD connector (Samtec)

Offline Crystal Recovery


- Annealing of crystals' radiation damage by irradiation with (visible) light from LED



- blue led flux $\approx 10^{16}$ photons/s
100% recovery after 160 min
- caveat: recovery amplitude includes effect from thermal spontaneous recovery

Offline Crystal Recovery

Recovery flux dependence, cold crystals, $D = 30$ Gy



- Blue LED flux measured with Ulbricht sphere and power-calibrated spectrometer
- Sequence: 1st irradi., light recovery, full thermal recovery, 2nd irradi., light recovery – same crystal

Offline Crystal Recovery

- molar mass of PWO 455.05 g/mol
- volume of full size crystal $\sim 100 \text{ cm}^3$
- color center concentration $\sim 10\text{-}20 \text{ ppm}$

$$N_{PWO} = 6.022 \cdot 10^{23} \frac{\text{atoms}}{\text{mol}} \cdot \frac{8.3 \text{ g}}{455.05 \frac{\text{g}}{\text{mol}}} \approx 1.1 \cdot 10^{22} \frac{\text{atoms}}{\text{cm}^3}$$

atoms in full size crystal $\sim 10^{24}$

$0.5\text{-}1.0 \cdot 10^{19}$ traps per crystal

Room temperature recovery data:

- Time for full recovery $\sim 100 \text{ min} = 6000 \text{ s}$
 - > total fluence $6 \cdot 10^{19}$ photons

Offline Crystal Recovery

- $0.5-1.0 \cdot 10^{19}$ traps per crystal
- recovery probability value = 0.1 (empirical)
- 1MeV should create 10^5 electron-hole pairs
 - 1Gy $\sim 10^{18}$ traps (with 100% efficiency)
 - PANDA irradiation $\sim 2 \cdot 10^{-6}$ Gy/s
 - Trap yield $\sim 2 \cdot 10^{12}$ traps/s
 - **4 weeks of runtime equals $5 \cdot 10^{18}$ traps**

**Recovery (95%) in 1.5...5 hours
at $T = -25^\circ\text{C}$ and 10^{16} photons/s**

Offline Crystal Recovery



Suggested LED:

KINGBRIGHT KA-2810AQBS-G



Blue, $\lambda(\text{max}) \sim 465\text{nm}$, efficiency ~ 0.35 , $U_f \sim 3.3\text{V}$, $I_f \sim 20\text{ mA}$, right angle radiance

Price: 0.478 Eur (4000+ pcs)



Offline Crystal Recovery



Suggested LED:

KINGBRIGHT KA-2810AQBS-G



Blue, $\lambda(\text{max}) \sim 465\text{nm}$, efficiency ~ 0.35 , $U_f \sim 3.3\text{V}$, $I_f \sim 20\text{ mA}$, right angle radiance

Price: 0.478 Eur (4000+ pcs)



Crystal Quality Screening

Test of Radiation Hardness of Ingots @ Microtron Lab of CTU

Irradiation of samples of the top and bottom part of the ingot

MT25 Facility at Prague

electrons: $5.5 \text{ MeV} < E_e < 16.6 \text{ MeV}$




homogeneous illumination of the (rotated) sample

integral beam intensity adjusted to radiation damage

caused by illumination with γ -rays (^{60}Co , 30Gy)

illumination for 5-10 minutes

immediate measurements of the **optical transmission** before
and after irradiation (sample thickness $\sim 10\text{mm}$)



fast response for immediate reactions of CRYTUR